

- 1 Casing
- 1E Cap Screw, Casing
- 2 Impeller
- 7 Casing Ring, *Optional*
- 14 Sleeve, Shaft

- 26 Cap Screw, Impeller
- 26A Washer, Impeller
- 27 Adapter Ring
- 28 Gasket, Impeller Screw
- 30A Gasket, Impeller Washer

- 32 Key, Impeller
- 38 Gasket, Shaft Sleeve
- 38A O-Ring, Shaft Sleeve
- 65 Seat, Mechanical Seal
- 71 Adapter

- 73 Gasket, Casing
- 80 Rotor, Mechanical Seal
- 99G Cap Screw, Adapter
- 212 Ring, Seal Retainer